



UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

FINISH:
Polished/Chrome

DEBUR AND
BREAK SHARP
EDGES

DO NOT SCALE DRAWING

REVISION

© Rainware Pty Ltd 2012

	NAME	SIGNATURE	DATE		
DRAWN	Stevan Balfour		19/12/2012		
CHK'D					
APPV'D					
MFG	RAINWARE Pty Ltd				
Q.A.					
				MATERIAL:	
				316 Stainless Steel/ Chrome Brass	
				WEIGHT:	

TITLE:	<h1>Bribie 2001</h1>
DWG NO.	
	A4
SCALE: Not To Scale	SHEET 1 OF 1

Bribie Wall Shower Installation Instructions

1. Turn off mains water supply.
2. Turn on garden tap to drain excess water and remove garden tap off outlet (if applicable)
3. Clean thread on outlet of old thread tape etc.
4. Slide cover plate over thread protruding from wall, wind thread tape over thread clockwise approximately 6-10 turns. Screw on new Pool Shower Tap until tight and $\frac{3}{4}$ " thread is in the upright position.
5. Slide on standoff clip up from the bottom of the shower pipe (Straight end)
6. Slide on service nut and nylon olive to bottom of the shower pipe.
7. Fit shower pipe onto shower tap and secure loosely with service nut. If shower rose is too high then remove from tap and cut shower tubing to length using a hack saw. (Shower rose face should be approximately 2 metres – 7' from ground level.)
8. Position shower pipe in place checking pipe is vertical with a level, position standoff clip about $\frac{3}{4}$ up the pipe just below bend. Mark holes on wall for screws using the standoff clip as a template. Drill holes using a 6mm masonry drill and tap in red plugs into wall, reposition shower tube and then screw in stainless screws through standoff clip.
9. Tighten service nut & nylon olive at bottom of shower pipe. Turn on mains supply and flush pipes checking for any leaks. Attach shower rose to bent end of shower pipe.
10. Clean your new stainless steel shower with the enclosed Hillmark Steelkleen wipe. The wipes are designed to remove finger prints, water marks and prevent brown staining. Should brown staining occur use a wet (Scotch Brite) green pot scourer with dishwashing detergent and rub up & down the shower. To keep your shower looking good wipe over your shower regularly with Steelkleen Stainless Steel spray (purchased through most supermarkets). We use 316 Stainless Steel which doesn't rust.

Thank you for purchasing a Rainware Pool Shower, your shower is now ready to use.

Warning: If the shower is in direct sunlight this could cause the water held in the shower or garden hose connecting the shower to heat up and cause scalding. Please ensure before using the shower to let water run for a few moments to washout any overheated water.



Rainbow Pool Products

PO Box 2388, Mansfield Qld 4122

Telephone STD 61-7-3849 5385

Facsimile STD 61-7-3849 5384

Email: info@rainbowpoolproducts.com.au

Web: www.rainbowpoolproducts.com.au