

Free Standing Beach Showers Installation Instructions

1. Select a position for your Pool Shower away from powerlines & power points. Shower Height is 2 mtrs.
2. Run plumbing underground using ½" poly or copper tube, bring plumbing pipe or pipes out of the ground approximately 2" (50mm) in the centre of the position of the shower. If shower position is beside a wall please position pipe work 200mm away from the wall to allow for the shower to be cleaned. (The shower has a 250mm square base). Showers are designed as cold only as there is no temperature control.
Note: Inline stop cocks or isolating valves should be installed before the shower to assist in repair if ever required, this is not compulsory however recommended.
3. Concrete or pave a level area approximately 400mm or bigger for the shower to be secured to. (Note: Pavers should be bedded in cement to add weight and stability)
Pipes should have lagging or protection from concrete (some plumbers use a short piece 100mm DWV / Sewer PVC pipe to protect the pipes. **Flush pipes with water to remove any dirt or pipe filings, these will affect performance of your shower.**
4. Cut the pipes to the desired length to make it easier to connect to flexi-connector. Using a compression fitting (1/2" C x MI Union) for copper or a Tita fitting (1/2"P x MI Connector) for poly, connect pipe work to the ½" FI Flexi-connector hanging out of the base of the shower.
5. When tightening to flexi-connectors no thread tape is required. **Hand tighten then nip (½ turn)** with spanner. Hoses will push inside shower when in upright position. Turn shower on to check for leaks!
6. Position shower in your preferred direction, mark & drill holes using a 12mm Masonry drill. To take out looseness or unevenness in shower, use silicone between shower base and concrete or paving. Tap in dynabolts supplied with a hammer gently and tighten with spanner.
7. Clean your new Pool Shower with a Hillmark Steelkleen stainless steel wipe. The wipes are designed to remove finger prints and water marks, and prevent brown staining. Should light scratching occur, use a Scotch Brite green pot scourer and rub up & down the shower, in the direction of the grain (not across the grain). Please be aware we use structural stainless steel and sometimes there are flaws or scratches in the tube. We do our best to try to remove these before manufacture.
8. For easy maintenance of your Pool Shower, wipe over regularly with Hillmark Steelkleen spray (purchased through most supermarkets)..

If a brown staining occurs:

We use 316 Stainless Steel which does not rust. If brown teastaining does occur, use a Scotch Brite and liquid dishwashing detergent as per instruction no.7 then rinse with clean water. With tapware & rose, closely determine the direction of the grain & apply detergent with Scotchbrite **gently with the grain** until all tea stain is removed.

Regular applications of Steelkleen helps prevent staining & keeps your shower looking good.

9. Thankyou for purchasing a Rainware Pool Shower. Your shower is now ready to use.

Please note: If shower is installed within 1200mm (4') of the pool water please connect earth wire. A qualified electrician must do connection as per AS3000 Electrical Code.

Warning: If the shower is in direct sunlight this could cause the water held in the shower or garden hose connecting the shower to heat up and cause scalding. Please ensure before using the shower to let water run for a few moments to washout any overheated water.



Rainbow Pool Products

PO Box 2388, Mansfield Qld 4122

Telephone STD 61-7-3849 5385

Facsimile STD 61-7-3849 5384

Email: info@rainbowpoolproducts.com.au

Web: www.rainbowpoolproducts.com.au