



FLIP n FILL INSTALLATION GUIDE

GARDEN HOSE VERSION

1. When installing your unit you must have the pool set to the correct water level to start.

Firstly find the correct ring to suit your particular skimmer box, screw it into place and put the two spare rings aside. This will now allow you to set up the unit to your pool.

2. Once the pool is at the correct level connect the hose to the top of the Flip N Fill by removing the Filler cap in the centre (store this somewhere safe!).

3. Now turn the hose on and the Flip N Fill will effectively start filling as when out of the water it thinks the water is low.

4. Now starting with the Float System, which slides up and down the white pipes at the top, slowly slip the float down into the water until the water stops flowing from the Flip N Fill.

5. Mark with a pen on the white pipes a mark, which is now the correct setting level of your Flip N Fill. So now when your pool water is down you can simply turn on the hose and leave it. When the pool water reaches the valve which you set to the correct level in the step above it will shut off the water.

PERMANENT

1. When installing your unit you must have the pool set to the correct water level to start.

2. Firstly run the 8mm tubing to the water supply and connect it to the Flip N Fill via a hole in the side of the skimmer box (as per installation guide in the pack). Find the correct ring to suit your particular skimmer box, screw it into place and put the two spare rings aside. This will now allow you to set up the unit to your pool.

3. Once the pool is at the correct level connect the 8mm tubing to the top of the Flip N Fill via the elbow connector and push in firmly. The Flip N Fill unit should not yet be sitting down in the skimmer box.

4. Now turn on the water supply and the Flip N Fill will effectively start filling as when out of the water it thinks the water is low.

5. Now insert the unit into the skimmer box and adjust the float up or down the white pipes until the water stops flowing from the Flip N Fill. The unit is now at the correct level.

6. Mark with a pen on the white pipes a mark, which is now the correct setting level of your Flip N Fill. So now when your pool water falls below this mark the float will fall and activate the valve to start filling. When the pool water reaches the valve which you set to the correct level in the step above it will shut off the water.



Rainbow Pool Products

PO Box 2388, Mansfield Qld 4122

Telephone STD 61-7-3849 5385

Facsimile STD 61-7-3849 5384

Email: info@rainbowpoolproducts.com.au

Web: www.rainbowpoolproducts.com.au