



Rainbow Pool Products

PO Box 2388, Mansfield Qld 4122 Telephone STD 61-7-3849 5385 Facsimile STD 61-7-3849 5384

Email: info@rainbowpoolproducts.com.au Web: www.rainbowpoolproducts.com.au

15205 - Connect Controller RF Remote Handset

The Connect Controller RF handset must be operated in conjunction with an AstralPool RF Remote Transceiver (10019) or Equipment Side Transceiver (10017). If either of these transceivers are not currently installed, please contact your local AstralPool dealer.

When installing a Connect Controller RF remote, please also refer to instructions within your Connect Controller operating and installation manual.

Connecting Handheld Transceivers

- Install the fixed Transciever(s) as per Viron Connect manual and then from the Install Transceivers menu:
- Press Connect Handheld Transceivers
- The following information screen is then shown:

Press and hold buttons 1 & 2 on each Handheld Transceiver for 5 seconds, until their lights flash. While they are still flashing, press Next. Please note that only new Handheld Transceivers will be connected.

- Press Next
- The following information screen is then shown:
 Now Connecting New Handhelds... 0 Handhelds connected.
- If the Handheld Transceivers Network ID is updated by this process, the Touchscreen will show how many Handheld Transceivers have been connected.
- NB If you repeat this process, without changing the Network ID the touchscreen will show 0
 Handheld Transceivers connected.
- Press Done
- Now press Back to configure the button layout on the Handheld.
- press Configure Handheld

Note: All channels and favourites should be assigned before the handheld device is programmed

For Button 1 Press the Configure button and the following options are displayed>
 What Action should be performed?

o None

Control Pool/Spa Equipment

Control Heating

 Activate a favourite eg using button.)

o **General Functions.** functions

Control Auxiliary Valves.

o Control Lighting.

This button will do nothing

This button is for general equipment such as pumps,

blowers, lights etc.

This button is used to turn Heating On or Off

This button is used to select a preassigned Favourite "Spa at Night" etc. (NB Favourites must be assigned the favourites menu before assigning a Handheld

This button is used to select All Auto or All Off

This option is only shown if Auxiliary valves are set up This option is only shown if lighting zones are set up. Options here are to Toggle a zone or multiple zones on or off or to cycle through colours if colour lighting is used

- Choose your desired Action and press Next
- Then select the desired function.
- Toggle equipment on/off

This is used to turn equipment on or off e.g. Blowers, Water Features etc. Pressing this button will toggle the equipment On then Off then On etc

or

Set equipment's mode

This is used to set the mode of equipment e.g. On, Off or Auto. Pressing this button will always turn the equipment to (say) On. Pressing it again will still turn it On. If you use this function you probably should set up one of the other buttons to turn the equipment off again or use one of the buttons to go to All Auto etc.

Repeat the above process for all of the buttons and then press Done.

LEDs on 8 Button Handheld Transceiver

- The top/center LED on the Handheld Transceiver illuminates whenever a button is pressed
- The LEDs above each button indicate that the Touchscreen has received and acted on the button push.
 - A solid LED indicates the following outcomes:
 - In the case of a Toggle command it will indicate that the Equipment is now On.
 - In the case of Mode setting it will indicate that the programmed mode has been set (e.g. On or Auto)
 - o A Flashing LED indicates the following outcomes:
 - o In the case of a Toggle command it will indicate that the Equipment is now Off.
 - o In the case of Mode setting it will indicate that the programmed mode has been set to Off
 - No LED indicates that the touchscreen hasn't received the information or the Handheld device hasn't received confirmation. Ensure that you are in range of the Touchscreen Transceiver or replace the battery.